

The manufacturer

STORENMATERIAL AG
Chrummacherstrasse 1
8954 Geroldswil
SWITZERLAND

declares that the following products

VANTA and VANTA+
AV-950 and AV-750
AV-900 and AV-700
AC-800 and AC-600
AF-800 and AF-500

are venetian blinds for outside use which comply with the prescriptions for the following standards:

EN 13659:2004	Shutters - Performance requirements including safety
98 / 37 / EC	Machinery directive
89 / 106 / EEC	Construction products
89 / 336 / EEC	Electromagnetic compatibility
73 / 23 / EEC	Electrical apparatus low voltage directive

Geroldswil, 01.10.2020

STORENMATERIAL AG

Rolf Zeller

Manager



Our venetian blinds comply with the prescribed **safety regulations**. However, an improper use can lead to damages to property and persons.

Please read the **operating instructions** carefully, before operating our venetian blinds. This will enable you to protect yourself and avoid damage to the product. Keep the operating instructions safely stored. Pass them on if you move house.

Operation should only be done by instructed persons. Children should not be allowed to play with venetian blinds or their operating parts. The remote controls should be kept out of reach of children.

One should not reach into moving parts while the venetian blinds are being opened or closed. Special care must be taken to avoid any items of clothing or parts of the body getting caught up and drawn in.

Defective venetian blinds should not be used, and must be repaired immediately by qualified technicians using original manufacturer's replacement parts. During **maintenance works** such as cleaning the facades or glass, motorized venetian blinds are to be disconnected from the mains supply. The same applies in the case of cleaning or repairs to the venetian blinds themselves.

Setting up electrical connections is to be done only by qualified electricians. Electrical parts which have been exposed due to damages should not be touched (e.g. cables, control components).

Closed venetian blinds **do not provide protection** against burglary or falling from an open window.

The **warranty** becomes invalid in the case of damages caused by failure to observe this leaflet or other accompanying documents.

Venetian blinds with manual drive are operated by means of a crank handle. The handle should always be held by both hands on the grips designed for this. Once the end stop is reached one should not continue to forcefully turn it. After operation is finished the handle should be carefully inserted back in the wall holder provided.

Venetian blinds with electric drive are operated by means of local or centrally situated wall switches or portable transmitters with up/stop/down keys. Where no stop key is provided, the drive is stopped by briefly pressing the key for the opposite direction.

In the event of strong **wind or hail** the venetian blinds should be raised in good time. For electrically operated shutter blinds the use of a control unit with integrated wind-monitoring is recommended.

In the case of **icing-up**, venetian blinds should not be operated.

Control units without an ice-warning monitor should be switched off in winter.

When lowering the venetian blinds care should be taken that **no obstructions are in the way of the slats' movement**.

To clean the slats, use lukewarm water to which a much diluted and mild cleansing agent has been added. It is applied to the slats with a soft cloth or a sponge, carefully wiping off the dirt. It is important to then rinse the slats well using clean water. One should not use alkaline, acidic or abrasive cleansing agents or high pressure steam methods!

The **side guide rails** are to be checked regularly for dirt and cleaned when necessary.

Venetian blinds are to be regularly inspected for **signs of wear**. Any defects should be immediately put right by qualified technicians.